

ULTRA-NET™ JR. *Portable Net System* By GOPHER

ASSEMBLY INSTRUCTION

Ultra-Net Assembly Instructions

1. Assemble the base frame first, working from one side to the other and fitting sections together as shown.
 - a. Locate one of the parts marked #1
 - b. Connect with one of the sections marked #2
 - c. Insert section #3 into the other end of part #2
 - d. Continue with 2 of the sections marked #7
 - e. Before connecting the 2nd section marked #7, slide piece #8 over the 2nd section #7.
 - f. Continue with the 2nd section #7, then #6, then the other section #2, and finally the other #1.
2. Insert the vertical post sections #4 for tennis (30" height) or sections #4 and #5 for badminton and volleyball (60" height).
3. Slip the net sleeves over the vertical posts, pushing the posts inward as needed to release tension.
4. Use the Velcro strap to further stretch the headband to eliminate sagging.

Note: The easy way to repeatedly assemble and disassemble the Ultra-Net is to leave the net over the end posts and simply roll the net up into the carry case.

Parts:

- 2 Ea - Corner Posts labeled #1
- 2 Ea - support beams #2
- 2 Ea - support beams #7
- 1 Ea - support beams #3
- 1 Ea - support beams #6
- 1 Ea - center support bracket #8
- 2 Ea - side post #4
- 2 Ea - side post #5
- 1 Ea - Net
- 1 Ea - Carry Bag

